

**Thank you for purchasing a Cornetto Soft cabinet.**

This guide is designed to ensure you get the optimum performance from your Cornetto Soft cabinet at all times.

By positioning and operating the cabinet correctly and then following a few steps to look after it, your Cornetto Soft cabinet will run properly and efficiently.



**Cornetto Soft**

### Positioning Your Cabinet

- A 5cm gap must be left between all sides of the cabinet and the wall or any other fixture or fittings. The grille at the rear of the cabinet must also be unobstructed at all times to allow continual airflow.
- Please note the cabinet will not perform in ambient temperatures over 35°C.

**5cm gap all around**



### Operating Your Cabinet

- The cabinet should be left to stand for 4 hours after delivery before being plugged in for the first time.
- The cabinet should be plugged into a suitable 13 amp electrical supply. It should be plugged directly into the mains supply socket and **not attached** to an extension lead or adaptor.
- It will take approximately 24 hours for the cabinet to get down to the required temperature. Ice Cream should not be put inside the cabinet until temperature has been reached.
- Once plugged in and switched on at the mains supply socket it will begin to work. **Please note** that there is no on / off switch.

## Operating Your Cabinet continued...

- This cabinet is not designed to be able to freeze liquid, eg. ice pops. These should be frozen before putting them in.
- Do not exceed the load line on the inside of the cabinet. Doing so will result in reduced performance of your cabinet.
- Always keep lids closed whenever possible.

### DO NOT EXCEED LOAD LINE LEVEL



## Temperature Adjustment



- If the correct temperature is not being maintained then adjustments to the cabinet can be made.
- The thermostat is located in the grille at the right hand side of the freezer. Access is through a small hole as illustrated. A flat blade screwdriver is required to adjust the thermostat.
- Adjust the temperature by turning the dial 1 increment clockwise to go colder or anticlockwise to go warmer.
- Leave the cabinet for 2 hours and then check the temperature again. Repeat this process if more adjustments are required.

## Looking After Your Cabinet

- Regularly (once a month) wipe off the outside of the compressor housing cover with a dry cloth to remove any dust or debris build up.
- **Health & Safety Caution:** Before removing the compressor housing cover, always isolate the unit by completely removing the plug from the power supply. All work on the electrical system and the refrigeration system must be performed by suitably qualified staff.



## Looking After Your Cabinet - Defrost

- When ice begins to build up in the cabinet (approximately 1cm or 1/2 inch thick) this indicates that defrosting is required. This should be carried out at least once every six months.
- Empty the cabinet of all products, isolate the unit by completely removing the plug from the power supply, open all lids.
- Place a tray under the external drain hole and remove the internal plug.
- To aid defrost place a container (5 - 10 litres) of warm water inside and close the lids. When the ice has melted sufficiently it can be removed.
- Never use sharp implements to scrape the ice as this may damage the walls.
- When the ice has melted and drained away dry off any residual moisture with a soft cloth.
- Refit the drain plug, plug back into power supply and close all lids. Please note that it may take up to 24 hours for the cabinet to get back down to temperature.

## Problem Solving

In the unlikely event that your cabinet is not operating to its optimum performance, you are responsible for ensuring that the following basic checks have been carried out **before** calling out an engineer.

### Cabinet not running correctly:

1. Check the electrical supply.
2. Check the fuse in the mains plug is OK.
3. Check the thermostat has not been lowered or turned off.
4. If the cabinet is plugged into an extension lead, unplug it and plug directly into the mains supply.

### Cabinet is not at the correct temperature:

1. Check that a good air space has been left around the cabinet.
2. Check the cabinet is not near a heat source.
3. Check the lids have not been left open.
4. Check the load line has not been exceeded.
5. Check the thermostat has been set correctly.
6. Check if there is a build up of ice inside.
7. Check the condenser grille is not blocked with dust or debris.



For further information on Green Benefits  
[www.wallsrefrigerationsolutions.com](http://www.wallsrefrigerationsolutions.com)



## Quick Start Guide

---

Cornetto Soft

### Warranty

Your cabinet is supplied with a 12 month parts and labour warranty to protect you against manufacturers defects. If you need assistance please call:

**Wall's Refrigeration Solutions Customer Service Department on 0845 127 2527**

In order to log a service call you will need to provide the serial number for the cabinet at fault. This can be found on the information plate that is located on the back of the cabinet. Use this space to make a note of the serial number for future reference using a ball point pen:

**SERIAL NUMBER**

Please note that the basic checks detailed in this guide are usually excluded from the warranty. See standard terms and conditions for further information.

**Non-warranty calls will be charged for.**

If you are in any doubt contact our Customer Services Department.

### Cabinet Contents Insurance

Please note that your cabinet warranty excludes any liability for loss of product or your insurance excess no matter how caused.

We recommend that you check your Store Policy to ascertain if you are covered for such an eventuality and if not then take separate insurance.

It is recommended that you leave your cabinet switched on for 24 hours before placing stock inside.

---

### Waste Electrical & Electronic Regulations (WEEE)

In accordance with the WEEE regulations, Wall's Refrigeration Solutions is responsible for the final disposal of all equipment purchased on or after the 13th August 2005 - customers will be charged for the distribution costs at the time of collecting the unit.

For equipment purchased before 13th August 2005 Wall's Refrigeration Solutions will make a commercial charge on the customer which covers both the disposal of the unit(s) and the associated distribution costs.



Unilever UK Ltd, Unit 2A, East Tame Business Park,

Rexcine Way, Talbot Road, Hyde, Cheshire, SK14 4GX Phone: 0845 127 2527 Fax: 0161 366 7374

Sales enquiries: [sales@wallsrefrigerationsolutions.com](mailto:sales@wallsrefrigerationsolutions.com) Service enquiries: [service@wallsrefrigerationsolutions.com](mailto:service@wallsrefrigerationsolutions.com)

[www.wallsrefrigerationsolutions.com](http://www.wallsrefrigerationsolutions.com)