

### Thank you for purchasing a B-Ice / Mini B-Ice.

This guide is designed to ensure you get the optimum performance from your B-Ice / Mini B-Ice at all times.

By positioning and operating the cabinet correctly and then following a few steps to look after it, your B-Ice / Mini B-Ice will run properly and efficiently.



B-Ice




Mini B-Ice

### Positioning Your Cabinet

- The cabinet should be positioned on a flat, level surface.
- A 5cm gap must be left between the rear/ends of the cabinet and the wall or any other fixture or fittings. The grille at the end of the unit must also be unobstructed at all times to allow continual airflow.
- Please note the cabinet will not perform in ambient temperatures over 35°C.
- Site the cabinet away from external sources of heat, eg. radiators, direct sunlight etc.

**5cm gap all around**




### Operating Your Cabinet

- The cabinet should be left to stand for 4 hours after delivery before being plugged in for the first time.
- The cabinet should be plugged into a suitable 13 amp electrical supply. It should be plugged directly into the mains supply socket and **not attached** to an extension lead or adaptor.
- It will take approximately 24 hours for the cabinet to get down to the required temperature. Product should not be put inside the cabinet until temperature has been reached.

## Operating Your Cabinet continued...

### DO NOT EXCEED LOAD LINE LEVEL



- This cabinet is not designed to be able to freeze liquid, eg. ice pops. These should be frozen before putting them in.
- Do not exceed the load line on the inside of the cabinet. Doing so will result in reduced performance of your cabinet.
- Always keep lids closed whenever possible.
- The on/off light switches are located at the top of the rear panel.



- The on/off switch is located at the top of the rear panel, you will need a pen or similar item to put through the hole and press the button.

## Temperature Adjustment

- If the correct temperature is not being maintained then adjustments to the cabinet can be made.



- There are two thermostats located on the rear control panel. The right hand thermostat (when facing it) controls the top tier and the left hand thermostat controls the bottom tier.
- Adjust the temperature by turning the dial 1 increment clockwise to go colder or anti-clockwise to go warmer.
- Leave the cabinet for 2 hours and then check the temperature again. Repeat this process if more adjustment is required.

## Looking After Your Cabinet

- Even though this cabinet is fitted with a low maintenance condenser that should not require cleaning for long periods of time, it should still be inspected at least once a year for signs of any substantial dust or debris build up.
- **Health & Safety Caution:** Before removing the compressor housing cover, always isolate the unit by completely removing the plug from the power supply. All work on the electrical system and the refrigeration system must be performed by suitably qualified staff.

## Looking After Your Cabinet - Defrost

- When ice begins to build up on the inside of the cabinet (approximately 1cm or ½ an inch thick) this indicates that defrosting is required. This should be carried out at least once every six months.
- Empty the cabinet of all products, isolate the unit by completely removing the plug from the power supply, open all lids.
- Place a tray under the external drain hole and remove the external & internal plugs.
- Never use sharp implements to scrape the ice as this may damage the walls.
- When the ice has melted and drained away dry off any residual moisture with a soft cloth.
- Refit the drain plug, plug back into power supply and close all lids. Please note that it may take up to 24 hours for the cabinet to get back down to temperature.

## Problem Solving

In the unlikely event that your cabinet is not operating to its optimum performance, you are responsible for ensuring that the following basic checks have been carried out **before** calling out an engineer.

### Cabinet not running correctly:

1. Check the electrical supply.
2. Check the fuse in the mains plug is OK.
3. Check the thermostat has not been lowered or turned off.
4. If the cabinet is plugged into an extension lead, unplug it and plug directly into the mains supply.

### Cabinet is not at the correct temperature:

1. Check that a good air space has been left around the cabinet.
2. Check the cabinet is not near a heat source.
3. Check the lids have not been left open.
4. Check the load line has not been exceeded.
5. Check the thermostat has been set correctly.
6. Check if there is a build up of ice inside.
7. Check the condenser grille is not blocked with dust or debris.

Your light tube(s) will eventually need replacing and you will need to purchase a new one.

Internal display: 30W T8 Daylight

Light tubes are available from The Light Bulb Co. Tel: 01869 362 222

### Warranty

Your cabinet is supplied with a 12 month parts and labour warranty to protect you against manufacturers defects. If you need assistance please call:

### Wall's Refrigeration Solutions Customer Service Department on 0845 127 2527

In order to log a service call you will need to provide the serial number for the cabinet at fault. This can be found on the information plate that is located on the back of the cabinet. Use this space to make a note of the serial number for future reference using a ball point pen:

**SERIAL NUMBER**

Please note that the basic checks detailed in this guide are usually excluded from the warranty. See standard terms and conditions for further information.

**Non-warranty calls will be charged for.**

If you are in any doubt contact our Customer Services Department.

### Cabinet Contents Insurance

Please note that your cabinet warranty excludes any liability for loss of product or your insurance excess no matter how caused.

We recommend that you check your Store Policy to ascertain if you are covered for such an eventuality and if not then take separate insurance.

It is recommended that you run your cabinet for 24 hours before placing stock inside.

---

### Waste Electrical & Electronic Regulations (WEEE)

In accordance with the WEEE regulations, Wall's Refrigeration Solutions is responsible for the final disposal of all equipment purchased on or after the 13th August 2005 - customers will be charged for the distribution costs at the time of collecting the unit.

For equipment purchased before 13th August 2005 Wall's Refrigeration Solutions will make a commercial charge on the customer which covers both the disposal of the unit(s) and the associated distribution costs.

