

Thank you for purchasing a CMV375 Drinks chiller.

This guide is designed to ensure you get the optimum performance from your CMV375 Drinks chiller at all times.

By positioning and operating the chiller correctly and then following a few steps to look after it, your CMV375 Drinks chiller will run properly and efficiently.



CMV375 Drinks chiller

Positioning Your Chiller

- The chiller should be positioned on a flat, level surface.
- A 5cm gap must be left between all sides of the chiller and the wall or any other fixture or fittings. The grille at the rear of the chiller must also be unobstructed at all times to allow continual airflow.
- Please note the chiller will not perform in ambient temperatures over 30°C.
- Site the chiller away from external sources of heat, eg. radiators, direct sunlight etc.

5cm gap at the rear/ends



Operating Your Chiller


- The chiller should be left to stand for 4 hours after delivery before being plugged in for the first time.
- The chiller should be plugged into a suitable 13 amp electrical supply. It should be plugged directly into the mains supply socket and **not attached** to an extension lead or adaptor.
- It will take approximately 4 hours for the chiller to get down to the required temperature. Product should not be put inside the chiller until temperature has been reached.
- Always keep the door closed whenever possible.

Temperature Adjustment



- If the correct temperature is not being maintained then adjustments to the chiller can be made.
- The thermostat can be found inside the chiller on the right hand upper rear, if adjustment is required turn the dial clockwise by 1 increment for colder or anti-clockwise for less cold, leave for two hours then check again and adjust more if required.

Looking After Your Chiller



- Regularly (once a month) check grilles at the rear of the chiller and brush all dust and debris away to allow ventilation.
- **Health & Safety:** All work on the electrical system and the refrigeration system must be performed by suitably qualified staff.

Problem Solving

In the unlikely event that your chiller is not operating to its optimum performance, you are responsible for ensuring that the following basic checks have been carried out **before** calling out an engineer.

Chiller not running correctly:

1. Check the electrical supply.
2. Check the fuse in the mains plug is OK.
3. Check the thermostat has not been lowered or turned off.
4. If the chiller is plugged into an extension lead, unplug it and plug directly into the mains supply.

Chiller is not at the correct temperature:

1. Check that a good air space has been left around the chiller.
2. Check the chiller is not near a heat source.
3. Check the door has not been left open.
4. Check the load line has not been exceeded.
5. Check the thermostat has been set correctly.
6. Check the condenser grille is not blocked with dust or debris.



For further information on Green Benefits
please see www.wallsrefrigerationsolutions.com

Warranty

Your chiller is supplied with a 12 month parts and labour warranty to protect you against manufacturers defects. If you need assistance please call:

Wall's Refrigeration Solutions Customer Service Department on 0845 127 2527

In order to log a service call you will need to provide the serial number for the chiller at fault. This can be found on the information plate that is located on the back of the chiller. Use this space to make a note of the serial number for future reference using a ball point pen:

SERIAL NUMBER

Please note that the basic checks detailed in this guide are usually excluded from the warranty. See standard terms and conditions for further information.

Non-warranty calls will be charged for.

If you are in any doubt contact our Customer Services Department.

Chiller Contents Insurance

Please note that your chiller warranty excludes any liability for loss of product or your insurance excess no matter how caused.

We recommend that you check your Store Policy to ascertain if you are covered for such an eventuality and if not then take separate insurance.

It is recommended that you run your chiller for 4 hours before placing stock inside.

Waste Electrical & Electronic Regulations (WEEE)

In accordance with the WEEE regulations, Wall's Refrigeration Solutions is responsible for the final disposal of all equipment purchased on or after the 13th August 2005 - customers will be charged for the distribution costs at the time of collecting the unit.

For equipment purchased before 13th August 2005 Wall's Refrigeration Solutions will make a commercial charge on the customer which covers both the disposal of the unit(s) and the associated distribution costs.

