

Quick Start Guide

Tornado V50 / V100

Thank you for purchasing a Tornado V50 / V100 cabinet.

This guide is designed to ensure you get the optimum performance from your Tornado V50 / V100 at all times.

By positioning and operating the cabinet correctly and then following a few steps to look after it, your Tornado V50 / V100 will run properly and efficiently.



Ben & Jerry's
Upright Vista



Tornado V100




Tornado V50

Positioning Your Cabinet

- The cabinet should be positioned on a flat, level surface and the levelling feet wound down.
- A 5cm gap must be left between the rear/ends of the cabinet and the wall or any other fixture or fittings. The grille at the end of the unit must also be unobstructed at all times to allow continual airflow.
- Please note the cabinet will not perform in ambient temperatures over 30°C.
- Site the cabinet away from external sources of heat, eg. radiators, direct sunlight etc.

5cm gap at the rear/ends



Operating Your Cabinet

- The cabinet should be left to stand for 4 hours after delivery before being plugged in for the first time.
- The cabinet should be plugged into a suitable 13 amp electrical supply. It should be plugged directly into the mains supply socket and **not attached** to an extension lead or adaptor.
- It will take approximately 24 hours for the cabinet to get down to the required temperature. Ice Cream should not be put inside the cabinet until temperature has been reached.
- Once plugged in and switched on at the mains and the on / off switch the cabinet will begin to work

Operating Your Cabinet continued...

- This cabinet is not designed to be able to freeze liquid, eg. ice pops. These should be frozen before putting them in.
- Do not exceed the load line on the inside of the cabinet. Doing so will result in reduced performance of your cabinet.
- Always keep the door(s) closed whenever possible.

DO NOT EXCEED LOAD LINE LEVEL



Temperature Adjustment



- If the correct temperature is not being maintained then adjustments to the cabinet can be made.
- The controller is located on the lower right front of the cabinet and can be adjusted by pressing the **SET** button. When **SET** is seen in the screen press **SET** again and adjust temperatures by pressing the up and down arrows, once the desired temperature is on the screen the controller will lock this in automatically, just leave it.
- Leave the cabinet for 2 hours and then check the temperature again. Repeat this process if more adjustment is required.

Looking After Your Cabinet

- **Health & Safety:** Before checking and cleaning the condenser the unit should be isolated by unplugging it.
- **Caution:** Before removing the compressor housing cover, always isolate the unit by completely removing the plug from the power supply. All work on the electrical system and the refrigeration system must be performed by suitably qualified staff.



Looking After Your Cabinet - Defrost

- A manual defrost should take place at least every 6 months to do this remove all stock and simply turn the cabinet off then unplug it. Remove any internal drain plugs and leave for up to 24 hours. When all the ice has melted wipe out the inside with a clean dry cloth, replace the drain plug and switch the power supply back on. It may take 24 hours to return to normal temperature.
 - Empty the cabinet of all products, isolate the unit by completely removing the plug from the power supply, open all door(s).
 - To aid defrost place a container (5 - 10 litres) of warm water inside and close the door(s). When the ice has melted sufficiently it can be removed.
 - Never use sharp implements to scrape the ice as this may damage the walls.
- Extra Defrosting**
- Your cabinet will automatically defrost twice a day. During times of exceptional humidity it may need an extra defrost.
 - To start an extra defrost simply press and hold the controller up arrow for ten seconds, the cabinet will now automatically defrost for 10 minutes, please note the cabinet will take up to 2 hours to fully recover temperature.

Problem Solving

In the unlikely event that your cabinet is not operating to its optimum performance, you are responsible for ensuring that the following basic checks have been carried out **before** calling out an engineer.

Cabinet not running correctly:

1. Check the electrical supply.
2. Check the fuse in the mains plug is OK.
3. Check the Controller has not lowered or turned off.
4. If the cabinet is plugged into an extension lead, unplug it and plug directly into the mains supply.

Cabinet is not at the correct temperature:

1. Check that a good air space has been left around the cabinet.
2. Check the cabinet is not near a heat source.
3. Check the door(s) has not been left open.
4. Check the load line has not been exceeded.
5. Check that the controller has been set correctly
6. Check if there is a build up of ice inside.
7. Check the condenser grille is not blocked with dust or debris.

Your light tube(s) will eventually need replacing and you will need to purchase a new one.

Top display: F18w T8 Cool white, Internal Display: F36 T8 Cool white Light tubes are available from The Light Bulb Co. Tel: 01869 362 222



Quick Start Guide

Tornado V50 / V100

Point of sale

Wall's ice cream branded point of sale is available from P.O.S. Direct. **Tel: 0845 600 6612**

Warranty

Your cabinet is supplied with a 12 month parts and labour warranty to protect you against manufacturers defects. If you need assistance please call:

Wall's Refrigeration Solutions Customer Service Department on 0845 127 2527

In order to log a service call you will need to provide the serial number for the cabinet at fault. This can be found on the information plate that is located on the back of the cabinet. Use this space to make a note of the serial number for future reference using a ball point pen:

SERIAL NUMBER

Please note that the basic checks detailed in this guide are usually excluded from the warranty. See standard terms and conditions for further information.

Non-warranty calls will be charged for.

If you are in any doubt contact our Customer Services Department.

Cabinet Contents Insurance

Please note that your cabinet warranty excludes any liability for loss of product or your insurance excess no matter how caused.

We recommend that you check your Store Policy to ascertain if you are covered for such an eventuality and if not then take separate insurance.

It is recommended that you leave your cabinet switched on for 24 hours before placing stock inside.

Waste Electrical & Electronic Regulations (WEEE)

In accordance with the WEEE regulations, Wall's Refrigeration Solutions is responsible for the final disposal of all equipment purchased on or after the 13th August 2005 - customers will be charged for the distribution costs at the time of collecting the unit.

For equipment purchased before 13th August 2005 Wall's Refrigeration Solutions will make a commercial charge on the customer which covers both the disposal of the unit(s) and the associated distribution costs.



Unilever UK Ltd, Unit 2A, East Tame Business Park,

Rexcine Way, Talbot Road, Hyde, Cheshire, SK14 4GX Phone: 0845 127 2527 Fax: 0161 366 7374

Sales enquiries: sales@wallsrefrigerationsolutions.com Service enquiries: service@wallsrefrigerationsolutions.com

www.wallsrefrigerationsolutions.com